



Scale: 0.334" = 1'

Robbins Engineering, Inc./Online Plus™

<p>Job <i>Patterns</i></p>	<p>Mark <i>R13</i></p>	<table border="1"> <thead> <tr> <th>Quan</th> <th>Type</th> <th>Span</th> <th>P1-H1</th> <th>Left OH</th> <th>Right OH</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>SCIS</td> <td>280000</td> <td>8</td> <td>0</td> <td>0</td> </tr> </tbody> </table>	Quan	Type	Span	P1-H1	Left OH	Right OH	1	SCIS	280000	8	0	0	<p><i>Single Drawing</i></p>
Quan	Type	Span	P1-H1	Left OH	Right OH										
1	SCIS	280000	8	0	0										